

PLEASE READ CAREFULLY

Before commencing any work, carefully inspect the floorcovering for any fault or defect before installing. If any fault or defect is found to have been evident at the time of installation, no claims will be accepted.

POST-INSTALLATION

Avoid sliding appliances and heavy items across the finished floor. Use hardboard or plywood and a hand dolly. To prevent scratching and indentations, use furniture glides and felt protectors.

Roller castor chairs should have “Type W” castors fitted (which must be undamaged) and are specially designed for use with resilient flooring.

Do not wet-wash or scrub the floor for at least seven days following installation.

UNDERFLOOR HEATING

Textures® LVT is guaranteed for use with electric and water-based underfloor heating (UFH) systems only.

The maximum permitted adhesive line/subfloor temperature is 27°C when in normal operation.

It is not necessary to turn off the UFH system completely prior to installation if it is turned down to an adhesive line/subfloor temperature of 12-15°C maximum 48 hours prior to installation.

After the flooring has been installed and allowed to acclimatise for 24 hours, gradually increase the UFH temperature by 3-5°C increments per day, until it reaches the maximum operating temperature of 27°C (adhesive line/subfloor temperature).

CLEANING AND MAINTENANCE

Maintain the installed floor at a temperature between 12-27°C throughout its service life.

Do not use steam cleaners as it may cause the layers to delaminate and it is not covered under the warranty.

Clean up spills and water immediately to prevent the risk of slips and accidents occurring and possible long-term damage to the floor.

WATERPROOF FLOORCOVERING

Textures® LVT can withstand short periods of continuous water exposure, such as washing machine or dishwasher leak accidents, but should not be immersed in water or flooded for an extended period. The product consists of various layers that may delaminate if subjected to long-term water immersion.

Prevent long-term damage to your floor by promptly cleaning up spills and water spillages.

Textures® LVT is not suitable for wetroom installations.

SCRATCH & DAMAGE PREVENTION

Take precautions to protect the floor when moving heavy objects to prevent permanent scratches and other damage.

Use wide floor protectors under tables, chairs, and heavy furniture to avoid permanent damage or excessive indentation.

Place walk-off mats at all entrances to protect the floor from water, grease, sand and grit.

During peak sunlight hours, use UV protection film, blinds or curtains to avoid discolouration and temperature variations that could damage the floor.

ROUTINE MAINTENANCE

Regular cleaning is important to prevent a build up of particles from abrading the surface of the floor. A soft brush, vacuum cleaner or spray mop are suitable for general cleaning.

For heavy soiling, use neutral PH cleaner. When using water or any cleaning liquid, make sure to squeeze out all excess water before cleaning. Immediately remove any stain-forming or aggressive substances from the surface.